

# Halsey Taylor Endura II Tubular Outdoor Fountain Pedestal Non-Filtered Non-Refrigerated Freeze Resistant

Model 4400FRK

### PRODUCT SPECIFICATIONS

Halsey Taylor Endura II Tubular Outdoor Fountain Pedestal Non-Filtered Non-Refrigerated Freeze Resistant. Features shall include 316 Stainless, Heavy Duty Vandal Resistant, Sealed Freeze Resistant. Furnished with Vandal Resistant bubbler. Product shall be Floor Mount/Freestanding, for Outdoor applications, serving 1 station(s).

Special Features:	316 Stainless, Heavy Duty Vandal		
	Resistant, Sealed Freeze Resistant		
Finish:	Powder Coat (12 Color Options)		
Bubbler Style:	Vandal Resistant		
Mounting Type:	Floor Mount/Freestanding		
Chilling Capacity:	Non-refrigerated		
Approx. Shipping Weight:	143 lbs.		
Installation Location:	Outdoor		
No. of Stations Served:	1		

\*\*When used in non-temperature controlled environments, unit(s) must be adequately winterized and/or protected from extreme heat to prevent damage where climates dictate.

- Base material constructed from 300 series stainless steel provides the ultimate corrosion protection from even the most corrosive elements.
- Sealed Freeze Resistant Valve System: Fully sealed freeze resistant system that minimizes chance of ground water contamination, and prevents drain water from mixing with fresh water. Designed for ground installation below the frost line.



#### **▼** Ships in multiple boxes.

A Century of Tradition and Quality.
For more than 100 years, Elkay has been making innovative products and providing exceptional customer care. We take pride in offering plumbing products that make life easier, inspire change and leave the world a better place.



#### PRODUCT COMPLIANCE

ASME A112.19.3/CSA B45.4
Buy American Act
NSF/ANSI 61 (Q≤1) & 372 (lead free)



Installation Instructions (PDF) - 97731C

Warranty pertains to drinking water applications only. Non-drinking water applications are not covered under warranty. Warranty (PDF)

PART:	QTY:
PROJECT:	
DATE:	
ADDDON/AL:	

In keeping with our policy of continuing product improvement, reserves the right to change product specifications without notice. Please visit for the most current version of product specification sheets. This specification describes product with design, quality, and functional benefits to the user. When making a comparison of other producers' offerings, be certain these features are not overlooked.



## Halsey Taylor Endura II Tubular Outdoor Fountain Pedestal Non-Filtered Non-Refrigerated Freeze Resistant

Model 4400FRK

Optional Accessories		
<u>4471LHB</u>	Locking Hose Bib  Spec Sheet (PDF)	
97890C	Accessory - Direct Bury Adaptor  Spec Sheet (PDF)	

In keeping with our policy of continuing product improvement, reserves the right to change product specifications without notice. Please visit for the most current version of product specification sheets. This specification describes product with design, quality, and functional benefits to the user. When making a comparison of other producers' offerings, be certain these features are not overlooked.

# Halsey Taylor Endura II Tubular Outdoor Fountain Pedestal Non-Filtered Non-Refrigerated Freeze Resistant

Model 4400FRK

# MOUNTING INSTRUCTIONS and PLUMBING INSTRUCTIONS


Site and drainage excavation is required for fountain installation. Refer to owner's manual for site preparation details. Provide solid, well-drained surface to mount pedestal fountain (concrete pad recommended) with adequate support (300 lb. load minimum). (6) 3/8" minimum fasteners (not included) should be attached securely to mounting surface in order to secure fountain, (Refer to rough-in diagram), and be sure to allow an opening for the freeze-resistant valve in the ground as shown in the installation instructions that accompany the fountain. (Refer to the rough-in diagram below). Refer to local codes for any additional requirements.

Locate and install plumbing through ground as required. Assemble fountain to prepared site and mounting pad.


NOTE: Fountain is not furnished with service valve.
Position pedestal over plumbing and secure base to fasteners.
Remove access panels and connect supply and water lines.
Turn on water supply and check for leaks. Refer to owner's manual for detailed instructions. Reassemble access panels to pedestal. Trap and service stop not included.

OPERATING PRESSURES: Supply water 20 - 105 psi maximum


#### **TOP VIEW**



#### DETAIL A AIR GAP / VACUUM BREAKER



# SANITARY FREEZE-RESISTANT VALVE GROUND INSTALL DETAIL 4" PVC 1/4 BEND SIDE VIEW



In keeping with our policy of continuing product improvement, reserves the right to change product specifications without notice. Please visit for the most current version of product specification sheets. This specification describes product with design, quality, and functional benefits to the user. When making a comparison of other producers' offerings, be certain these features are not overlooked.